



NOTE:

- Route crack, Layer sand, Fill with Flexible Joint Material to 3" on either side.
- Place Reinforcing tape into Flexible Joint Material.

CRACK (SLIGHT MOVEMENT)

CONTROL JOINT DETAIL (LESS THAN 1/16")

35a