



**NOTE:**

- Route crack, Layer sand, Fill with Flexible Joint Material to 3" on either side.
- Place Reinforcing tape into Flexible Joint Material.

**CRACK (SLIGHT MOVEMENT)**  
**CRACK DETAIL (LESS THAN 1/16")**